

How to Enable Reporting Service?


Introduction

Peplink Reporting Service provides traffic statistics reports of your network performance drawn from live and historical data. It is a free (and optional) service to monitor the network(s) for all your Balance devices.

How to use Peplink Reporting Service on Balance

Post Data

1. Open the Balance admin page and go to **System > Reporting Server**.
2. To use the default Peplink reporting server, select **Yes** in the **Post Data to Server?** field.
3. Click **Save** and **Apply Changes** by clicking the button in the right hand corner of the page.



Note: you may require to register a login ID and assign the device with the login ID first before using this service. See below sections for more details.

Register a Report Account

Before using reporting service, you need a valid user account on reporting server. As a new user, please follow the steps below to register:

1. Click on the **create a login** link on the Balance admin page or go to Peplink reporting server (<http://report.peplink.com>) to **Register Report Account**.




The screenshot shows the Peplink Balance Reporting Server 4.8.9 login interface. At the top, the title is "Peplink Balance Reporting Server 4.8.9". Below the title is the Peplink logo and the text "Balance Reporting Server". The main section is titled "User Report Login" and contains two input fields: "Username" and "Password". Below these fields are two links: "Register Report Account" and "Forgot Password". A "Login" button is located at the bottom right of the form. At the very bottom, there is a copyright notice: "Copyright (c) Peplink. All Rights Reserved."

2. Enter your detailed user information on the **Account Registration** page.
3. An e-mail will be sent to your e-mail address and follow the instructions in your e-mail to activate your account.

Update Balance Device(s)

1. On the Balance admin page, **Specify** your **User Account** registered and click **Update**. It will associate this Balance with the specified user account on the server.
2. If you have more than one Balance device, you need to login to the admin page of each Balance device, and update your account on the Reporting Server Registration window.

Reporting Server Registration



The screenshot shows the Reporting Server Registration form. It has a text input field labeled "User Account *" with a small asterisk. Below the input field is a blue text warning: "Registration will contact the reporting server to associate this Peplink Balance with the specified user account on the server. Make sure you have a valid user account before this registration." Below the warning are two buttons: "Update" and "Cancel". At the bottom, there is a text input field labeled "Reporting Server:" with the value "report.peplink.com" entered.

View Reports

1. Login to Peplink reporting server (<http://report.peplink.com>). Your management devices list will be displayed on the interface.

Note: No Balance device is seen when log in with a brand new account.




Logged in as demo | Logout

| Peplink Balance Reporting Server | | | | |
|----------------------------------|-------------|---------------------|----------------------|--------|
| Your managed Peplink Devices | | | | |
| Serial Number | Description | Peplink Product | Report | Remove |
| 1824-1234-5678 | Home | Peplink Balance 20 | View | |
| 1824-2345-6789 | Branch A | Peplink Balance 310 | View | |
| 1824-ABCD-1234 | HQ | Peplink Balance 710 | View | |
| 1824-ABCD-5678 | Branch B | Peplink Balance 380 | View | |

[Change Device Description](#)

- To display individual device statistics, click **View** next to the selected device. You can view traffic statistics for both inbound and outbound by WAN link and standard protocol.

The illustration below shows a daily report of a Balance 710 device:



By pointing towards a particular WAN connection, a number showing the absolute usage would be shown as above.

Disclaimer: This how-to document may not contain the most up-to-date information. Please refer to the User Manual for official product information.

About Peplink

Peplink is the proven market leader in delivering Internet link load balancing solutions. Peplink's products have been deployed by service providers, public safety agencies, city governments and enterprise customers around the world. As an innovative creator of technology solutions, Peplink operates globally with offices in North America and Asia in cooperation with distributors, system integrators and strategic alliance partners.

Document Rev. 2010-6

Contact Us

<http://www.peplink.com/contact/>

Sales

<http://www.peplink.com/contact/sales/>

Support

<http://www.peplink.com/contact/support/>

©2010 Peplink International Ltd. Peplink and the Peplink logo are trademarks of Peplink International Ltd. Other brands or products mentioned may be trademarks or registered trademarks of their respective owners.

Specifications are subject to change without prior notice. Please visit our website for accurate and update specifications.